

Frameless mirror harness

Disconnect original mirror and harness from car and remove mirror

Install new mirror assembly

Connect the mirror harness inline with the mirror harness in the car and the new mirror.

Route the wires along the front edge of the headliner and down the driver's side A-pillar. You do not have to remove the A-pillar just simply tuck the wires into it.

Remove the access panel on the driver's side of the dashboard. Locate and remove the 20 amp fuse that is located in circuit #17. Install the 20 amp fuse into my fuse assembly so that it now has 2 fuses in it. Then install the assembly back into #20.

The green wire will get connected shortly

Underneath your upper console trim you will see the harness that feeds the upper console. Plug the second half of the mirror harness into this harness and re-connect. Then plug the green wires together and you are good to go.