

XLR to Anderson

Output Adapter for the Cycle Satiator Charger with Andersons for connecting to battery, and a TRS Cable for communications.





Grin Technologies #205-950 Powell St Vancouver, BC V6A 1H9

info@ebikes.ca www.ebikes.ca

Part #: XLR_Anderson

- High Current (15A) Neutrik XLR connector
- TRS jack for connecting Satiator to PC using TTL-USB cable
- Genuine Anderson Powerpoles

Specifications

Cable Length 6cm

Input Connector XLR Neutrik NC3FXX

Pin1 = DC +, Pin2 = DC -, Pin3 = Signal

Output Connector Anderson Powerpole PP30

Communication TRS Jack

Tip=Rx, Ring=TX, Sleeve=Gnd

For more information, visit www.ebikes.ca



Advancing the world of ebike parts and accessories

www.ebikes.ca