



Instructions

READ AND UNDERSTAND ALL INSTRUCTIONS AND WARNINGS BEFORE USING.

OWB P100 Series

Includes:

- + Interchangeable paddle and belt loop. Both offer adjustable cant.
- + Snap-in tabs provided for use with belt loop to accommodate various belt widths
- + Optional spacer included to hold holster with more clearance from upper body so gun butt does not dig into wearer's side...comfortable for women and full-bodied men. Additional spacing pads are included for additional adjustability regarding pitch angles of holster ride.
- + Additional longer screws for use with spacer and spacing tabs.

IWB P110 Series

Includes: Swivel Belt loop.

The Delta Wing series is molded specifically to fit a particular firearm or series of firearms. Please review the label information to help ensure that your holster is the proper size for your weapon. As with any new piece of equipment, you must familiarize yourself with the holster. **READ AND UNDERSTAND THESE INSTRUCTIONS AND WARNINGS COMPLETELY BEFORE USING THIS HOLSTER.** Then practice drawing and replacing the weapon until you are completely familiar with the holster's use. **PRACTICE WITH AN UNLOADED WEAPON.**

This holster series offers some adjustments for your convenience. Please read the following instructions before attempting any adjustments. **IMPORTANT:** Make any adjustments or changes to the holster configuration **WITHOUT A WEAPON** in the holster. The holster **MUST BE EMPTY.**

PADDLE: If this holster is delivered with the paddle attached, the paddle can be adjusted to three positions: a forward cant, a straight-up-and-down position, or a rearward/cross-draw angle. To change the position of the paddle, use a #2 Phillips screwdriver to remove the three mounting screws. Reposition the paddle to the desired angle. Replace the screws and tighten firmly.

To wear the holster, insert the paddle holster into your pants' waistband, grip the **EMPTY** holster body with your shooting hand and tip the holster muzzle forward. With your other hand, open a small space between your body and the inside of your pants where the holster will be worn. Insert a corner of the paddle into this space and gently push the paddle downward while at the same time rotating the holster to a muzzle-down position. The holster will remain outside of the belt and waistband.

To remove the paddle holster, grip the **EMPTY** holster body with your shooting hand. Gently pull the bottom of the holster body (very slightly) away from the pants. At the same time, pull the holster body upward as you rotate the holster to a muzzle forward position (the reverse of the insertion motion).

BELT LOOP: To change to the belt loop (or change the position of the belt loop), use a #2 Phillips screwdriver to remove the three mounting screws. Note the word **FRONT** molded into the belt loop. This belt loop is designed to be most comfortable when the word **FRONT** faces forward. This is true for right and left-handed users. Position the belt loop onto the holster in the desired position. Replace the screws and tighten firmly.

The belt loop will accommodate pants belts from 1-1/4" to 2" in width. For belts narrower than 2 inches, snap-in tabs are provided to adjust the size of the belt slots. These tabs are to be snapped in place by hand into the belt slots. You may use either of the two sizes of tabs, or both sizes together, depending on your belt width. You may slide the tabs to the top or bottom of the belt slots. This allows you to insert your belt through the belt slots above or below the tabs, so you can choose how high or low the holster rides.

SPACER: An optional triangular spacer is also provided to allow the holster body to be worn slightly away from the wearer's body. Some women, stout men, or those who need the holster to clear ballistic vests or other garments may prefer to use the spacer. Please note that to utilize this spacer between the paddle or belt loop and the holster requires the use of three longer screws, which are included. Of the three longer screws, two are 5/8" in length and one is 1/2" in length.

Additional Spacing pads are also included to assist the user in adjusting the pitch angle of holsters ride on the hip. This is a matter of taste and can depend on where on the waist (2 o'clock, 4 o'clock, etc.) thus user prefers to wear the holster.

To install this spacer, remove the three original mounting screws from the holster and **SAVE** them. You will need these three original screws if you ever decide to wear the holster without the spacer. Position the spacer over the three protruding mounting nuts with the **FLAT SIDE** of the spacer against the holster. Position the paddle or belt loop over the spacer and align the mounting holes for the desired drawing angle. Carefully start the two 5/8" screws in the two top holes and the 1/2" screw in the bottom hole. Lightly screw in all three screws deeply enough so that the screws go through the paddle or belt loop and spacer and start into the holster body. Then, tighten each screw firmly.

P110 Series (IWB):

IWB Delta Wing holsters come equipped with a swivel belt loop. Note that the tension screw on the swivel belt loop may be left semi-loose to allow the holster to rotate with body movement, or the belt loop may be positioned at the user's preferred angle of wear, and the tension screw tightened to fix the belt loop in that position.

Gould & Goodrich
709 E. McNeill St.
Lillington, NC 27546 USA

Customer Service - (910) 893-2071
Toll Free in U.S. - (800) 277-0732
gouldusa@gouldusa.com

